





## FELIX TABLE LAMP ASSEMBLY INSTRUCTIONS



horgans.com.au



## THIS ARTICLE REQUIRES ASSEMBLY

## THE BOX INCLUDES

- 1 Lamp Shade (A)
- 2 Lamp Base (B)
- 3 Top Nut (C)
- 1 Unscrew the top nut (C) from the top movement of the lamp.
- 2 Secure the Light Bulb (H) E27 into the bulb holder (I).
- 3 Carefully place the shade (A) over the top of the movement of the lamp & align so that the top nut (C) can be re-screwed.
- 4 Slightly move the shade to check it is adequately tightened. If it feels loose, tighten top nut (C) until fim
- 5 Adjust the lamp shade to a straight position if appearing to tilt to The side
- 6 The lamp is ready to use.

Please note: Bulb is not included Uses E27 MAXIMUM 40W

## **SAFETY WARNING**

- To prevent risk of fire, do not use light bulbs greater than 40 Watt.
- If the external flexible cable or cord of the lamp needs to be replaced, it should only be replaced by a qualified Electrician.